PAMS Technical Documentation
NSB-8 Series Transceivers

Service Tools

Issue 1 01/02
©Nokia Corporation

Table of Contents

Page No

JBV-1 Docking Station and MJF-6 Adapter 4
Product Code 4
MJS-46 Module Jig 6
Product Code 6
MJS-47 Soldering Jig 7
Product Code 7
FPS-8 Flash Prommer (Sales Pack) 8
Sales Package Code 8
FPS-8C Parallel Flash Prommer (Sales Pack) 9
Sales package code 9
ACF-8 Universal Power Supply 10
Product Code 10
FLA-18 POS (Point Of Sale) Flash Loading Adapter 11
Product Code 11
FLC-2 DC Cable 12
Product Code 12
AXS-4 Service Cable 13
Product Code 13
XCS-1 Service Cable 14
Product Code 14
SW Security Device PKD-1 15
Product Code 15
FLS-4 POS (Point Of Sale) Flash Device (Sales Pack) 16
Product Code 16
PCS-1 Power Cable 17
Product Code 17
XRF-1 RF Cable 18
Product Code 18
DAU-9S MBUS Cable 19
Product Code 19
SCB-3 DC Cable 20
Product Code 20
XCS-4 Modular Cable 21
Product Code 21
Printer Cable 22
Product Code 22

Page No

©Nokia Corporation

List of Figures

Page No

Fig 1 View of JBV-1 and MJF-6 together 5
Fig 2 View of MJS-46 6
Fig 3 View of MJS-47 7
Fig 4 View of FPS-8 8
Fig 5 View of FPS-8C 9
Fig 6 View of ACF-8 10
Fig 7 View of FLA-18 11
Fig 8 View of FLC-2 12
Fig 9 View of AXS-4 13
Fig 10 View of XCS-1 14
Fig 11 View of SW Security Device 15
Fig 12 View of FLS-4 16
Fig 13 View of PCS-1 17
Fig 14 View of XRF-1 18
Fig 15 View of DAU-9S 19
Fig 16 View of SCB-3 20
Fig 17 View of XCS-4 21
Fig 18 View of Printer Cable 22

©Nokia Corporation

JBV-1 Docking Station and MJF-6 Adapter

The JBV-1 Docking Station has been designed for calibration and software update use. The MJF-6 Docking Station Adapter makes signal connections to the phone. JBV-1 and MJF-6 are used as one unit.

JBV-1 main electric functions are:

- adjustable VBATT calibration voltage, current measurement limit voltage "VCHAR", current measurement calibration current "ICHAR"
- adjustable ADC calibration voltage via BTEMP and BSI signal
- BTEMP and BSI calibration resistor
- signals from FBUS to the phone via parallel jig
- control via FBUS or USB
- Flash OK/FAIL indication

In the calibration mode, the JBV-1 is powered by an external power supply 11-16V DC. During flashing, power for the phone can be taken from the FPS-8 or from an external power supply 11-16V DC.

The MJF-6's main electric functions are:

- phone recognizing from BTEMP
- filters of FBUS signals
- SIM CARD reader

Product Code

JBV-1 Docking Station:	0770298
MJF-6 Docking Station Adapter:	0770317

©Nokia Corporation

Figure 1: View of JBV-1 and MJF-6 together



CPL-6 RF-Coupler: 0775308
CPL-6 is used with JBV-1 and MJF-6 for making RF coupler connection from the phone to measurement equipment.



©Nokia Corporation

MJS-46 Module Jig

The MJS-46 Module Jig is used for testing of UI/system/RF-module*.

Product Code

MJS-46 Module Jig: 0770316

Figure 2: View of MJS-46



**Note: The nominal supply voltage for MJS-46 is +8.0 V. The supply voltage must not exceed +12.0 V (min. 5V). (MJS-46 has overvoltage protection). For flashing with FPS-8, it is possible to bypass the regulator with a jumper. Then the supply voltage must not exceed 5.2 V.*

©Nokia Corporation

MJS-47 Soldering Jig

The Soldering Jig MJS-47 is used for soldering and as a rework jig for system module.

Product Code

MJS-47 Module Jig: 0770342

Figure 3: View of MJS-47



©Nokia Corporation

FPS-8 Flash Prommer (Sales Pack)

The Flash Prommer FPS-8 is used with e.g. FLA-18 and JBV-1. Power is supplied to FPS-8 from the Universal Power Supply.

The sales pack includes:

- FPS-8 Flash Prommer 0750123
- FPS-8 Activation Sheet 9359289
- Universal Power Supply 0680032
- AXS-4 Service Cable (D9-D9) 0730090
- Printer cable 073F000

Sales Package Code

FPS-8 Flash Prommer: 0080321

Figure 4: View of FPS-8



©Nokia Corporation

FPS-8C Parallel Flash Prommer (Sales Pack)

The Parallel Flash Prommer FPS-8C is used with MJF-6 and JBV-1. Flash programming can be done to maximum of 8 phones parallel. FPS-8C consists of eight SF11C programming cards. SF11C card is functionally identical to FPS-8.

Sales package code

FPS-8C Parallel Flash Prommer: 0080396

Figure 5: View of FPS-8C



©Nokia Corporation

ACF-8 Universal Power Supply

ACF-8 Universal Power Supply is used to power FPS-8. ACF-8 has 6 V DC and 2.1 A output.

Product Code

ACF-8 Universal Power Supply:	0680032

Figure 6: View of ACF-8



©Nokia Corporation

FLA-18 POS (Point Of Sale) Flash Loading Adapter

The POS Flash Loading Adapter FLA-18 is used in place of the phone's normal battery during service, to supply a controlled operating voltage.

Product Code

FLA-18 POS Flash Loading Adapter: 0770318

Figure 7: View of FLA-18



©Nokia Corporation

FLC-2 DC Cable

The FLC-2 is used to supply a controlled operating voltage.

Product Code

FLC-2 DC Cable: 0730185

Figure 8: View of FLC-2



©Nokia Corporation

AXS-4 Service Cable

The AXS-4 D9-D9 Service Cable is used to connect two 9 pin D connectors e.g. between PC and FPS-8. Cable length is 2 meters.

Product Code

AXS-4 D9-D9 Service Cable: 0730090

Figure 9: View of AXS-4



©Nokia Corporation

XCS-1 Service Cable

The XCS-1 Service Cable is used to connect FLS-4 to FLA-18.

Product Code

XCS-1 Service Cable:	0730218

Figure 10: View of XCS-1

©Nokia Corporation

SW Security Device PKD-1

SW security device is a piece of hardware enabling the use of the service software when connected to the parallel (LPT) port of the PC. Without the dongle present it is not possible to use the service software. Printer or any such device can be connected to the PC through the dongle if needed.

Caution: Make sure that you have switched off the PC and the printer before making connections!

Caution: Do not connect the PKD-1 to the serial port. You may damage your PKD-1.

Product Code

SW Security Device PKD-1: 0750018

Figure 11: View of SW Security Device



FLS-4 POS (Point Of Sale) Flash Device (Sales Pack)

FLS-4 is a dongle and flash device incorporated into one package, developed specifically for POS use.

Product Code

Sales Pack - Europe/Africa	0081483
Sales Pack -APAC	0081481
Sales Pack -Americas	0081482

Figure 12: View of FLS-4

©Nokia Corporation

PCS-1 Power Cable

The PCS-1 Power Cable (DC) is used to connect, for example, JBV-1 to FPS-8.

Product Code

PCS-1 Power Cable: 0730012

Figure 13: View of PCS-1



©Nokia Corporation

XRF-1 RF Cable

RF cable XRF-1 is used to connect, for example, the Module Jig MJS-46 to the RF measurement equipment.

Product Code

XRF-1 RF Cable: 0730085

Figure 14: View of XRF-1



©Nokia Corporation

DAU-9S MBUS Cable

The MBUS Cable DAU-9S has a modular connector, and is used with between PC's serial port and, for example, the Module Jig MJS-46.

Product Code

DAU-9S MBUS Cable: 0730108

Figure 15: View of DAU-9S



SCB-3 DC Cable

The DC Cable SCB-3 is used to connect, for example, the JBV-1 to the phone.

Product Code

SCB-3 DC Cable: 0730114

Figure 16: View of SCB-3



©Nokia Corporation

XCS-4 Modular Cable

XCS-4 is a shielded cable (one specially shielded conductor) modular cable for flashing and service purposes.

Product Code

XCS-4 Modular Cable: 0730178

Figure 17: View of XCS-4



©Nokia Corporation

Printer Cable

This cable is used to connect the PC to FPS-8.

Product Code

Printer Cable: 073F000

Figure 18: View of Printer Cable



©Nokia Corporation